

# WriteAway **Installation Instructions**

The following are installation instructions for Identity Ink's WriteAway, Clear film. These instructions should be followed by your installation technicians, employees and/or maintenance personnel as failure to follow them will irrevocably void the warranty.

## TOOLS REQUIRED

- Teflon or other soft edge film squeegee;
- Spray bottle;
- Application fluid;
- Rubber squeegee;
- OLFA snap-off knife w\ 9mm stainless steel blade;

## INSTALLATION INSTRUCTIONS FOR POLYESTER FILM:

1. Confirm dimensions and sizing of material is correct by placing the piece over the existing smooth panels, there should be an approximate 1" overlap of the film on all four sides of the panel.
2. Clean the entire surface with a light misting of water and rubber squeegee.

***NOTE: It is recommended to run your bare hand across the panel to ensure no contaminates or debris are left behind during the cleaning process.***

3. Mix the application fluid, for example, Film On or similar solution with balanced pH levels, in spray bottle as per manufacturers recommendations, this will allow the film to slide during installation.
4. Apply a light mist of the application fluid to the panel.
5. Begin peeling the backer material from the WriteAway, Clear film in the corner, misting the adhesive side of the surface prior to touching with bare skin.
6. Continue peeling the backer from the film, misting across the entire adhesive surface of the film.
7. Apply the film to the glass tile allowing the entire surface to come in contact.
8. Slide the film to cover the existing glass tile keeping in mind the 1" overlap of the material on all four sides or alignment to existing artwork if applicable.
9. Lightly mist the surface of the WriteAway, Clear film.
10. Along the top edge of the film use the Teflon squeegee with 75% pressure to move the water from the centre to both sides.
11. Squeegee the remaining water from the top of film to bottom starting from the centre and moving to both sides.
12. Using the OLFA knife and edge of squeegee, cut excess film along all sides where applicable.

# WriteAway **Installation Instructions**

13. Repeat a light mist on the surface of the WriteAway film.
14. Using the Teflon squeegee go over the entire surface of the film at 100% pressure to ensure all remaining application fluid is removed.
15. Wipe the entire surface of WriteAway, Clear film.

**NOTE: Some miliness or residual water maybe trapped beneath the film, this will evaporate and disappear within two weeks.**

## **CAUTION**

For day to day instructions, be sure to follow the cleaning procedures outlined in the WriteAway Care & Maintenance document available at [www.identityink.ca](http://www.identityink.ca)

***If you have any questions, please contact Identity Ink at 403-724-9235 or email us at [orders@identityink.ca](mailto:orders@identityink.ca)***